

HOW TO WRITE HONDA CIVIC RH850 R7F701x CLEAR FILE

1. Connect all points like on connection diagram
2. Run CPT.exe and select correct CPU name and number
3. Add .rh850 clear file by "Clear" button
4. Uploaded file **must have the same number** as SRS unit number
5. CPT software write .rh850 file started
6. After finish write process, all done :-)

Watch video: https://youtu.be/4Ds7_QCVZ6s



Best Regards
CarProTool Support Team

