

HOW TO WRITE RENESAS H8SX CLEAR FILE

1. Connect cable like on connection diagram
2. Connect power adaptor and usb cable to CPT programmer
3. Run cpt.exe latest version
4. Select UART and CPU name
5. Find clear file in database on support web
<http://carprotool.com/forum/pinouts>
6. Click "Write" button add clear file to buffer in cpt.exe
7. Wait for finish ... it is all :-)

Watch video: https://youtu.be/Bz_1gNtna64



Best Regards
CarProTool Support Team

