

1. Connect cable like on connectoin diagram
2. Connect ACP12E NOKIA power adaptor and usb cable to cpt programmer.
3. Run cpt exe.
4. Select correct cpu name and number
5. Find clear file in database on support web www.carprotool.com/software
6. Click "Clear" button in cpt exe and add correct clear file for your srs unit number.
7. Wait for finish ... it is all :-)