

RCD310 / RCD510 PIN code reader

1. Read dump from 95128 and save on HDD.
2. Connect cable to navi main pcb (description available on support web page)
3. Select: Car Radio >> VW >> RCD510 [d70f3356 + 95128]
4. Select Read Code from operation list and click Do Job button
5. Wait for moment when cpt ask you for 95128 dump.
6. Add dump 95128 and wait for PIN CODE