

F2MC-16LX MB90495G Series
MB90497G/F497G/F498G/V495G

FPT-64P-M06

=====
=====

pin 26 P00
pin 27 P01

When the original oscillation is 4, 8 and 16MHz set P00 and P01 to "L".
When the original oscillation is 5 and 10MHz set P00 to "H" and P01 to "L".

pin 22 MD2 "H"
pin 21 MD1 "H"
pin 19 MD0 "L"

pin 20 RST => CPT1
pin 61 SIN1 => CPT5
pin 63 SOT1 => CPT6

pin 57 VCC => CPT2
PIN 25 GND => CPT9

FPT-64P-M23

=====
=====

pin 25 P00
pin 26 P01

When the original oscillation is 4, 8 and 16MHz set P00 and P01 to "L".
When the original oscillation is 5 and 10MHz set P00 to "H" and P01 to "L".

pin 21 MD2 "H"
pin 20 MD1 "H"
pin 18 MD0 "L"

pin 19 RST => CPT1
pin 60 SIN1 => CPT5
pin 62 SOT1 => CPT6

pin 56 VCC => CPT2
PIN 24 GND => CPT9